

Aloha, Walkingbass Players!

You can order a set from
<http://www.konawalkingbass.com>

This package contains a set of strings for the three string "Slack Key"-style bass. It is tuned to a major G chord. The thickest (lowest) string being G. The middle string is B. The thinnest string is D.

These strings will last for several years in this tuning. (They will stretched if tuned to higher notes, which may make them unuseable when tuned back down to G-B-D.)

When you decide to change your strings, cut the used strings on the bass in half with a sharp knife or pair of scissors. You can then remove each half easily from each end of the bass.

Then replace each string by first threading the bridge (lower) end. It is easiest to start with the middle (B) string. Feed the string through the bridge and down through the bass.

Crimp or knot the string with a pair of pliers (look at the string you are removing to see what it should look like.

Once the bass end of the string is secure, feed the string through the nut and the tuning machine. Allow at least an inch and a quarter of string to stick out of the back of the tuning machine. Center the bridge on the pickup ...and you're ready to play again!

Aloha,
-Konabob